
# **□SS** ⊂ ∈ −3 SERVICE NOTES




Base (2235030500)


	PARTS LIST				РСВ		
	2201015800 2218052500	Case Pedal	light blue metallic light blue metallic		7522251001	Ass'y ET5222-510 LED mounting	(pcb 2291055200) (pcb 2291049600)
)	2202011600 2235030500	Cover Base	bottom bottom		IC		
	2235030400 2215070201	Base Guide bushing	pedal matt		15189102 15189115	NJM4558DD TL022CP	op amp op amp
+物 強 +	2216050200 2217010900	Spacer Coil spring	pcb-bottom cover		15219211 15219210	MN3207 MN3102	BBD BBD driver
É	- 2226030500 2247012700	Cushion Knob			TRANSISTOR		
224055766	13419206 JACK	Battery snap SL-21	02		15129104 15129108	2SC732TM-GŘ 2SC945-P	FET
	13449104 13449105	SG-7713#4 SG-7615	IN <b>P</b> UT OUTPUT		15139101 DIODE	2SK30ATM-Y	rei
	13449704	HEC-0749-01-010	adaptor		15019125 15019209T0	1SS133 S5500G	
	<b>SWITCH</b> 13129710 13119101	JM-0404 SRU-1022	key rotary		15019526 15029117	RD5.6EB-3 SLP-135B	zener LED
O	POTENTIOMETER		LED.PCB 1日 229/0498の Tギリカパイプ T LED RATE, DEPTH crimmer SN2873のよず 229/0578の1 TR-2 T LED 12064308 Printed in Japan BC				o° + LED
	13279710 13229140	K121B00ME-100kB H0651A-10kB	RATE, DEPTH trimmer	5N28730	osy新 229/0.	57800 + TR-2	t LED
	<b>■</b> Roland				•	/206436 Printed in	Japan BC-2 1

Decoration screw 3 x 10mm

# ET5222-510 (7522251001) (pcb 2291055200)



### **ADJUSTMENT**



Set controls as shown left. Feed a signal 200Hz, +2dBm, sine into INPUT jack.

Connect an oscilloscope to Q8

Determine the BBD bias by turning VR-3 to provide a centered operating-point.

## **WAVEFORMS**

